



Download:

<http://download.bimserver.org/0.1/>

Make sure Java v6 is installed or get it at www.java.com/getjava/

Location of the stand alone (jetty)server:

<http://localhost:8081/>

Inlog/wachtwoord:

admin/admin

Difference between downloading and checkout:

Downloading the model returns the model as an IFC (step) file. Checkout gives the same result, but the bimserver will register which objects (including revision) you have downloaded. By doing this, the server can later find out what you have changed.

ChangeSet:

A changeSet is an XML file, according to the BIEP soap protocol, with the changes of the model (additions, deletions, modifications of objects).

Anonymous user:

When the anonymous user has rights on a project, everybody (using a webbrowser or soap client) is able to reach the data (without being logged in). This is not possible when the anonymous user doesn't have rights on a project.

Using this feature the bimserver (and your bim model) can be used as an object library.

Sourcecode:

find the source at:

<svn://svn.e-bouw.org/bimserver/java/tags/0.1stable/>
(user/password = anonymous/anonymous)